



**Loading & Firing Instructions for
The Big Shots® Confetti Cannons
110 Volt AC**

To fill the barrels with confetti or streamers:

- 1) For a full load you will need 1 # of confetti or 2 sleeves streamers per barrel. If you are using both confetti and streamers in the same barrel, load the streamers first.
- 2) Insert the lifting cup it is brown paper that is 2 cups glued together. Insert 1 in each barrel.
- 3) Add 1 # of confetti to each barrel
- 4) Place a paper compression cap over the mouth of the barrel. It is black and says "Artistry in Motion". Firmly press the cap to the barrel while tightly wrapping the black masking tape around the barrel & the lip of the cap. Do not tape across the top! You are now ready to arm the cannon.

To pressurize the Cannon:

- 1) Insert the Schrader valve into the top of the cannon where the quick connect fitting is. The air filler is attached to the cannon and is inside one of the barrels/
- 2) In order to fire confetti or streamers the accumulator tank needs to be filled with compressed air. The intake valve for the Big Shot® is the Schrader valve located on the top of the unit. This is the same valve used on automobile tires.
- 3) Attach the air hose and air chuck to the air compressor.
- 4) Press down the air chuck from a compressor to the Schrader valve and turn on the compressor. You want to fill the cannon to 100 - 120 psi. Do not over pressurize the tank. The maximum pressure for the tank is 125 psi. If the cannon is over pressurized the safety valve will pop, reducing the pressure to below working levels. If the cannon is firing too far, you may reduce the pressure to fit your needs. We do not recommend using pressures less than 60 psi as the results are erratic.

To Fire the Cannon:

- 1) Take the plug (the male Edison cord) from the bottom / back side of the Big Shot® and connect it to the momentary button.
- 2) Plug the momentary cord into your house power.
- 3) Press the button to fire the confetti cannons.

VERY IMPORTANT:

NEVER PLUG A 110 VOLT SYSTEM INTO POWER WHEN CANNONS ARE LOADED UNLESS TO FIRE!!!

SPECIAL EFFECTS CAN BE DANGEROUS. Please carefully read the above directions before use. Adults who have been properly instructed in their use should use the cannons. Never point a cannon at anyone or anything. Use at your own risk..

****IF FURTHER INSTRUCTION IS NEEDED, PLEASE CALL 718-875-0140** e-mail: info@jmfx.net**