



Instructions

Ultra Handy Fogger

- 1. Plug in power cord to back of the machine and then plug into a standard wall outlet.**
- 2. Once plugged in the light on the back of the machine will flash slowly. When the coil is close to being ready the light will flash faster.**
- 3. The coil is completely heated when the light is solid. It takes approximately 6.5 minutes**
- 4. The fogger will produce smoke for approximately 5 minutes of heavy use or up to 30 minutes of light use.**
- 5. The machine needs to be re-heated when it starts to produce less smoke and/or starts to spit a little fluid.**